

AC-L113UV RGBWUV LED Stage Light

| | | | | | | |
|-------------|---|--------------|--------------|--------------|--|-------------------------|
| DMX | → | d.001 | | | 1 - 512 | |
| PERS | → | STAG | | | 10 Channel DMX 1 . Dimmer, 2. Red, 3. Green, 4. Blue, 5. UV (Amber), 6. White, 7. Preset colours, 8. Strobe speed, 9. Programs (221-240 sound control), 10. Speed of programs | |
| | | ARC.1 | | | 3 Channel DMX 3 Channel DMX: 1. Red, 2. Green, 3. Blue | |
| | | ARI.d | | | 4 Channel DMX 4 Channel DMX: 1. Dimmer, 2. Red, 3. Green, 4. Blue | |
| | | ARC.2 | | | 5 Channel DMX 5 Channel DMX: 1 . Red, 2. Green, 3. Blue, 4. UV (Amber), 5. White | |
| | | AR2.d | | | 6 Channel DMX 6 Channel DMX: 1. Dimmer, 2. Red, 3. Green, 4. Blue, 5. UV (Amber), 6. White | |
| | | AR2.5 | | | 7 Channel DMX 7 Channel DMX: 1 . Dimmer, 2. Red, 3. Green, 4. Blue, 5. UV (Amber), 6. White, 7. Strobe | |
| | | HSV | | | 3 Channel DMX 3 Channel DMX: 1. Hue, 2. Saturation, 3. Brightness | |
| Id | → | Id.01 | | | 1-66 | |
| TEMP | → | CURR. | | | 0 | |
| | | TOP | OBS | | 20 - 150 (default = 85) | |
| EDIT | → | PR.01 | → | SC.01 | → | R.000 0 - 255 |
| | | ↓ | ↓ | | G.000 0 - 255 | |
| | | PR.10 | SC.30 | | B.000 0 - 255 | |
| | | | | | Y.000 0 - 255 | |
| | | | | | W.000 0 - 255 | |
| | | | | | ST.00 0 - 20 Strobe | |
| | | | | | T.000 0 - 255 | |
| | | | | | F.000 0 - 255 | |
| SET | → | UPLd. | | | | |
| | | REST. | | | | |
| | | Id. | → | OFF. | | |
| | | | | ON. | | |
| | | RGBW. | → | OFF. | | |
| | | | | ON. | | |
| | | POW. | → | HIGH. | | |
| | | | | NORM. | | |
| | | dim. | → | OFF. | | |
| | | | | dim1. | | |
| | | | | dim2. | | |
| | | | | dim3. | | |
| | | | | dim4. | | |

| | | | | | |
|------|---|-------|---|-------|----------|
| CAL1 | → | WT.01 | → | R.000 | 0 - 255 |
| | | ↓ | | G.000 | 0 - 255 |
| | | WT.11 | | b.000 | 0 - 255 |
| | | | | Y.000 | 0 - 255 |
| | | | | W.000 | 0 - 255 |
| CAL2 | → | RGbW. | → | R.000 | 25 - 255 |
| | | | | G.000 | 25 - 255 |
| | | | | b.000 | 25 - 255 |
| | | | | Y.000 | 25 - 255 |

| | | | |
|------|---|-------|-------------------------------|
| STAT | → | R.000 | 0 - 255 Red Brightness |
| | | G.000 | 0 - 255 Green Brightness |
| | | b.000 | 0 - 255 Blue Brightness |
| | | Y.000 | 0 - 255 UV (Amber) Brightness |
| | | W.000 | 0 - 255 White Brightness |
| | | ST.00 | 0 - 20 Strobe Speed |

| | | |
|------|---|-------|
| AUTO | → | AT.01 |
| | | AT.02 |

| | |
|-------|---------------|
| AT.03 | Colour Fading |
|-------|---------------|

↓

AT.10

PR.01

↓

PR.10

| | | | |
|-------|---|------|------------------|
| SOUND | → | MOD1 | Sound activation |
| | | MOD2 | |

| | | |
|-----|---|------|
| RUN | → | DMX. |
| | | SLAV |